


Future Foresee **MASSAGE CHAIR**
A39-1 Operation Instructions

SAVE THESE INSTRUCTIONS



Thanks for purchasing this product. Please read this manual instruction carefully in order to know how to use this product correctly before operation. Please pay more attention to some important safety warning and keep this manual book properly for future use.

Note: Our Company reserves the right to revise the design and description of this product without any further notice. Please refer to the actual color of this product.

CONTENTS

| | |
|---------------------------------|----|
| Safety and maintenance | 02 |
| Name and function of components | 04 |
| Function | 05 |
| Method of usage | 06 |
| Product specification | 19 |

Safety and maintenance

1. Important Safety Warning.

- Don't allow children to touch moveable part of this product.
- Please use well-grounding power supply suited to this product.
- Please pull out the plug after use or before cleaning to avoid injury or Damage to the product.
- Please operate this product according to this manual instruction.
- Don't use accessories which are not recommended.
- Don't use this product outdoors.
- Please read this manual instruction carefully before operation.
- Any other usage that is not listed in this manual instruction is forbidden.
- 20 minutes of usage each time is recommended.
- Please don't use it if the leather is broken or damaged.
- Please don't use it if the cover or leather is damaged.
- Please don't use it if the radiator hole is covered or blocked.
- Please don't drop anything into this product.
- Please don't fall asleep while using this product.
- Please don't use it if drunk or feel unwell.
- Please don't use it within one hour after having meal.
- Please don't make the massage function too strong for avoiding Injury.

2. Environment for usage.

- Please don't use it under high temperature and moist environment such as bathroom.
- Please don't use it immediately while the environmental temperature changes sharply.
- Please don't use it under heavy-dusty or caustic environment.
- Please don't use it where there is not enough space or not good ventilation.

3. People who are not suitable to use this product.

- People who are suffering from osteoporosis are not suitable to use this product.
- People who are suffering from heart disease or carrying electronic medical equipment such as heart pacemaker are not suitable to use this product.
- People who are suffering from fever are not suitable to use this product.
- Pregnant women or women that are in menses period are not suitable to use this product.
- People who got injured or skin disease are not suitable to use this product.
- Children under 14-year old or people mentally unbalanced without being Supervised are not allowed to use this machine.
- People who are told by doctor to have rest or people who feel unwell are not suitable to use this product.
- People whose bodies are wet are forbidden to use this product.
- The appliance has a heated surface. persons insensitive to Heat must be careful when using the appliance.

4. Safety.

- Check the voltage if it is suitable to the specification of this product.
- Don't use wet hand to pull the plug.
- Don't make water go inside this product to avoid electric shock or cause damage to this product.

Safety and maintenance

- Don't damage the wires or change the circuit of this product.
- Don't use wet cloth to clean the electric parts such as switch and plug.
- Be away from this product under power cut state to avoid injury if the power comeback suddenly.
- Stop using this product while it works abnormal, and please consult local agent immediately.
- Stop using this product if you feel unwell, and please consult health care doctor.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- If the supply cord is damaged, it must be replaced by the manufacturer, its Service agent or similarly qualified persons in order to avoid a hazard.


5. Maintenance.

- This product should be maintained by certain appointed agents, users are prohibited to disassemble or maintain by themselves.
- Please don't forget to cut the power after usage.
- Don't use this product if the socket looses.
- If this product will be left unused for long, please curl up the wires and reserve this product in dry and dustless environment.
- Don't reserve this product under high temperature or near fire and avoid longtime direct sunshine.
- If the detachable cord / supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a Hazard.
- Please clean this product by dry cloth. Don't use thinner, benzene or alcohol.
- The mechanical components of this product are specially designed and made, it is not necessary to be specially maintained.
- Don't use edged res to thrust this product.
- Don't roll or pull this product above uneven ground, it should be lifted before moving.
- Please use it intermittently; don't make this product work continuously for long.

6. Solution of ordinary malfunctions.

- It is nature movement voice if the motor sounds while in usage.
- If the controller can't work normally, please check the plug and socket if they are connected strongly and make sure the switch is turned on.
- If the rated working time is over, the product will automatically activate the power-off button; If this product works continuously for long, the temperature protector will make the product automatically power-off, it should be used again after half an hour's rest.

Name and function of components




Function

- Designed with a set of vertically movable, four wheel driven muted intelligent massage hands
- Designed with emulation massage methods of shiatsu, kneading, flapping, knocking, simultaneous kneading and flapping
- Set with the shoulder automatic detection and location
- Set with characterized auto massage function: ache-improving, comfort, ease, fast improving experience massage, upper body, lower body six kinds of automatic.
- Set with memory set on function M1 and M2
- Manual massage for the upper body with three options, fixed, partial and overall massage, with five levels of speed adjustable. in the state of flapping, shiatsu and knocking, the width between the two kneading balls is adjustable with three Levels: wide, medium and narrow. On partial and fixed point, the massage hands can move up and down to adjust the massage point accurately.
- Air pressure massage function with three modes :full body air pressure, arms (upper arm set with 4 airbags, arm set with 8 airbags),leg set with 8 airbags, three intensity optional.
- Back heating function: carbon fiber far infrared heat source
- Right arm is equipped with a USB charging function and lie-down function.
- Backrest frame down slides used technology to deviate from the wall by keeping zero space, reach the maximum space saving
- Leg lifting adjusting, the backrest frame lifting adjusting and automatic lay down mode adjustment function
- L shape back track fitting curves of the body, can realize the zero gravity when back down.
- Rating working time can be set and saved by remote controller, and also can control by the timer device.

Method of usage


Note: The specific displays refer to the actual object of this product!



06

Method of usage


1. Switch power supply on



2. Start to massage

- 1). Press power button, massage chair automatically reclining, and start massage.
- 2). Automatic shoulder position and massage acupressure point detection, waiting for the completion of testing.
- 3). If there is difference with the massage balls and the actual shoulder position, you can adjust the up and down button to a suitable position. Shoulder position has 10 grades adjustable. It will run automatic massage if there is no adjustment on shoulder position within 10 seconds.

| Button | Description | Display |
|----------------------------------|--|---------|
| Adjust shoulder (up/down arrows) | Move the massage balls upward to a suitable position | ↑ |
| | Move the massage balls downward to a suitable position | ↓ |



4) Choose massage function to massage

Memory function massage

Press button "Upper body / M1" or "Lower body / M2" for 3 seconds, then enter into memory massage function "M1" or "M2", it will revert to the previous memory massage mode.

| Function | Button | Display |
|----------------|---------------|---------|
| Memory massage | Upper body M1 | Memory |
| | Lower body M2 | Memory |

07

Method of usage

- Characterized auto massage

| Function | Button | Feature | Display |
|----------------------------|--------|---|---------|
| Characterized auto massage | | Deeply massage on acupressure points, effectively alleviate pain | Auto F1 |
| | | Loosen body physique | Auto F2 |
| | | Promote blood circulation | Auto F3 |
| | | Fast to experience all the massage effect (press for 2S, switch to speed press) | Auto F0 |
| | | Massage focus on upper body | Auto F4 |
| | | Massage focus on lower body | Auto F5 |

- Upper body manual massage, lower body manual massage

1) Upper body manual massage

| Function | Button | Adjust Massage Ball | Display |
|-----------|--------|--------------------------------|---------|
| Technique | | Speed And Width | |
| | | Speed | |
| | | Speed And Width | |
| | | Speed | |
| | | Speed And Width | |
| Speed | | Three Grades Speed Adjustable | |
| Width | | Three Grades Widths Adjustable | |

Method of usage

| Function | Button | Adjust Massage Ball | Display | |
|--------------|--------|--|------------------------|--|
| Back Stretch | | Fixed position (fixed point) massage back and forth | | |
| | | Small area (partial area) massage back and forth | | |
| | | Overall massage back and forth | | |
| | | Upper body massage back and forth | | |
| | | Lower body massage back and forth | | |
| | | Massage point adjust (in fixed point, partial modes you can adjust the massage position) | Massage hand move up | |
| | | | Massage hand move down | |

- Air pressure function massage

| Function | Button | Description | Display |
|-------------------|--------|--|-------------|
| Air pressure mode | | Three air pressure modes (full body, arm and leg) for Lower body | Arm Feet |
| Intensity | | With three grades adjustable | Arm Feet |

- Heating function


| Function | Button | Description | Display |
|----------|--------|---|---------|
| Heating | | Far infrared back heating, has warm feeling when it start to work 3 minutes later | |

- Other manual function

| Function | Button | Description |
|------------------------|--------|--|
| Calf rise and drop | | Calf rest lifting button, press this button, calf rest lifting slowly, stop when release it. |
| | | Calf rest decline button, press this button, calf rest decline slowly, stop when release it. |
| Backrest rise and drop | | Backrest lifting button, press this button, backrest lifting slowly, stop when release it. |
| | | Backrest decline button, press this button, backrest decline slowly, stop when release it. |
| Auto lay down mode | | with three modes circulation function, when press the button, turn into auto lay down mode. |

Method of usage

3.USB recharging function and lie-down function.



| Function | Button | Description |
|------------------------|--------|---|
| Switch | | Press to open and close the massage function. |
| USB | | USB recharging port, recharge smart devices (such as mobile phone). |
| Calf rise and drop | | Calf rest lifting button, press this button, calf restlifting slowly, stop when release it |
| | | Calf rest decline button, press this button, calf rest decline slowly, stop when release it |
| Backrest rise and drop | | Backrest lifting button, press this button, backrest lifting slowly, stop when release it |
| | | Backrest decline button, press this button, backrest decline slowly, stop when release it |

4.Rating working time set function

1).Remote set Rating working time: time socket plug in or out.

| Function | Button | Description | Display |
|---------------------|--------|--|-------------------|
| Rating working time | | In the standby state, press this button to set the rated working hours, according to their own needs within 1-30 minutes to set any massage time, the default is 20 minutes. | 20 _{Min} |
| Confirm button | | Press this button to confirm the setted massage Rating time | 20 _{Min} |

2). Timer device control rating working time: Plug in the timer socket.

- The operating time of the massage chair is controlled by the timer, and the massage chair can not be turned on before the timer is started, only after the timer to start, then the start working


Method of usage

5.Turn off power, stop massage

- 1)Press power button during massage progress, all massage function will be stop immediately, the backrest and footrest will return to original position automatically, meanwhile you can set up memory function. After rated working time, all massage functions will be finished, meanwhile you can set up memory function, but backrest and footrest won't return to original position.
- 2)Memory store function: After rated working time or switch off, the hand controller displays "Memory" and glitter, remind the users whether need to store the massage mode before turn off, you can press the memory function buttons "M1" or "M2" as you like, store the massage mode.

3) Cut off the power of the whole machine.

Figure (Switch power off)



Set with safety switch in a power supply box, if there is heavy pressure on power supply box, then forced stop back lying function, prevent hurts peoplewhen lying.

Method of usage

6. Armrest disassembly method

Note: this method is only use for cannot easy move into small space, such as too small room door, please do not arbitrarily disassemble.

- Open the master carton, take down the calf rest. (figure 1)
- Remove the back cushion (note: please ensure the heat wire in the cushion was unplugged before remove). (figure 2)




Figure 1




Figure 2

- Zip the backrest kneading cloth open completely, put the cloth on the top of chair (note: please remember to prevent the kneading cloth from dirty or damage). (figure 3)
- The calf rest decoration cover is card slot design, make an effort to pull it when disassembly. (figure 4)




Figure 3




Figure 4

- Unscrew the 8 screws of front dam-board (NEED NOT unscrew the 4 screws on the bottom). (figure 5)
- Open the front dam-board, unplug the joint of air pipe and power cord corresponding to armrest. (figure 6)




Figure 5




Figure 6

Method of usage

- Unscrew the screw on the front-end of armrest (note: the screw is in the side of steel frame). (figure 7)
- Unscrew the screw on the front-end of armrest (note: be careful not missing the plastic block for fixed). (figure 8)




Figure 7




Figure 8

- Unscrew the screw on the back-end of armrest (note: zip the backrest kneading cloth open completely, you may find it). (figure 9)
- Gently lift up the front-end of armrest, pull out the buckle. (figure 10)




Figure 9




Figure 10

- Gently pull forward the back-end of armrest to pull out the decoration cover, then lift up the back-end of armrest to pull out the buckle. (figure 11)
- Unplug the joint of upper armrest air pipe (figure 12), the armrest removed completely.




Figure 11




Figure 12

Method of usage

7. Armrest installation method

- Connect the air pipe on the back-end of armrest to the upper arm's. (figure 1)
- Put the air pipe and power cord into the steel frame (avoid the air pipe stuck). (figure 2)




Figure 1



Figure 2

- Hook the back-end of armrest on the steel frame (please note there are two, place it on the upper one). (figure 3)
- Insert the back-end of armrest into the decoration cover of upper arm. (figure 4)




Figure 3




Figure 4

- Hook the front-end of armrest on the steel frame and lock the buckle. (figure 5)
- Gently push the armrest down, double check if the hook well locked. (figure 6)




Figure 5




Figure 6

- Put the plastic block between the armrest and calf rest pothook, then tighten the up & down screws. (figure 7)
- Tighten the screws on the back-end of armrest. (figure 8)




Figure 7




Figure 8

Method of usage

- Connect the joint of air pipe and power cord (note: there's marks on the air pipe and size of cable connectors is different, you won't miss it). (figure 9)
- Pull the calf rest air pipe and power cord through the hole of front dam-board, then tighten the screws of dam-board. (figure 10)




Figure 9




Figure 10

- Zip the backrest kneading cloth up. (figure 11)
- Plug the heat plug of the back cushion into the heat hole on the backrest, put the back cushion tidily on the backrest. (figure 12)




Figure 11




Figure 12

- The calf rest decoration cover is card slot design, make an effort to push it when assembly (note: please keep the cover tight with the side), armrest installation is completed. (figure 13)




Figure 13

Method of usage

8. Footrest installation instructions

- Install the rotating shaft in calf fixed axis first, noticed the hole should be aligned, so that the R shape pin assembly (Figure 1)
- After calf is connected with the fixed axis aligned, then insert (Figure 2)




Figure 1




Figure 2

- Plug R pin, then moved to the other side of the calf, and the plug R pin (Figure 3)
- Finished (Figure 4)




Figure 1




Figure 2

Note

- When the machine under the working state, with lying and calf rest lifting, you could not apply gravity on the calf, to prevent the massage chair does harm to people before dumping (figure 1).
- Ensure the mechanism hands not in the seat part, otherwise will cause uncomfortable in the Buttock when you seating in the chair (figure 1).




Figure 1





Figure 2

Method of usage


9. Pillow and backrest pad's dismounting and use manual

Using pillows can reduce the kneading massage intensity on shoulder and neck, according to your needs to decide whether the pillow pad is needed (recommend headcushions). Backrest cushion and backrest connected by zipper (1), head cushion and backrest pad connected by thread gluing (2)



10. Floor Protection

Put the heavy massage chairs on the wood floor for a longtime may damage the floor, so please place a carpet or other object to avoid this damage.




Caution: Do not move the chairs with its wheels on wood floor, rough ground or in a narrow space. Two people are required to lift the chair. During the lifting period, the windscreen and backrest cover grooves as the focal point (Please do not lift armrest directly)

Method of usage

11. Method of movement

Make sure that all wires are far above the ground, tilt the backrest backward to a certain degree (with the gravity center resting on the wheels), push the chair forward or backward with your hands and finally resume the chair to the normal position in a slow and gentle manner.



Note: During movement you must turn off the power switch first and then unplug the power line and hand controller connecting line.

Product specification

Model: A39

Configure: 1

Name: Massage Chair

Rated voltage: 110-120V~ 60Hz
220-240V~ 50Hz/60Hz

Rated power input: 150W

Rated time: 20Min

Safety structure: Class I

Material introduction: PVC, PA, steel parts and electric & electronic parts

| MATERIAL | PU | LEATHER | CLOTH | WOOD |
|----------|----|---------|-------|------|
| | | | | |